


Outdoor Wicker Swivel Rocker Chair CO7152



PART LIST

A	B	C	D	E	
Arm Panel 2 PCS	Back Panel 1 PC	Seat Panel 1 PC	Lower Front Panel 1 PC	Base 1 PC	
F	G	P	Q	*Please note cushion covers w ship separately.	/ill
Cover of Seat Cushion * 1 PC	Core of Seat Cushion 1 PC	Cover of Back Cushion * 1 PC	Core of Back Cushion 1 PC		

HARDWARE LIST


Η	1	J	Κ	L
				\bigcirc
M6*30mm	M6*40mm	M6*50mm	M6mm	M6mm
Short Bolt 1 PC	Medium Bolt 4 PCS	Long Bolt 10 PCS	Nut 14 PCS	Washer 29 PCS
Μ	Ν	0		
5	a la			
M6mm	M6mm			
Wrench 1 PC	Allen Key 1 PC	Adjustable Leveler 6 PCS		

EXTRA HARDWARE LIST


Н		J	K	L
				\bigcirc
M6*30mm	M6*40mm	M6*50mm	M6mm	M6mm
Short Bolt 1 PC	Medium Bolt 1 PC	Long Bolt 2 PCS	Nut 3 PCS	Washer 3 PCS

Step 1. Lay Arm Panel (A)down on a flat surface. Attach Back Panel(B) to Arm Panel(A) using the Medium Bolts(I), Washers(L), Nuts(K), Wrench(M) & Allen Key(N).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2. Attach Seat Panel(C) to Arm Panel(A) and Back Panel (B) using the Long Bolts(J) Washers(L), Nuts(K), Wrench (M) & Allen Key (K)




J		4
Κ	6	4
L	0	8

Step 3. Attach Lower Front Panel (D) to Arm Panel (A) using the Long Bolts(J), Washers (L), Nuts(K), Allen Key (N) & Wrench (M), to Seat Panel (C) using Short Bolts (H), Washers (L) & Allen Key (N).




Step 4. Attach the other Arm panel(A) to the assembled Parts (A,B,C&D) using Medium Bolts (I),Long Bolts (J),Washers (L),Nuts (K),Wrench (M) and Allen Key (N) as shown.






Step 5. Screw the Adjustable Levelers(O) into the pre-drilled holes on the Base(E).Attach Base(E) to the Seat Panel(C).



Step 6.Insert core of seat cushion (part G) into cover of seat cushion (part F). Insert core of back cushion (part Q) into cover of back cushion (part P).



Step 6. Place Seat Cushion and Back Cushion on the Chair.

