







































Kitchen Island
CF3033



PART LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Partition Panel 1 PC	Bottom Panel 1 PC
F 	G 	H 	I 	J 
Top Cross Rail 1 PC	Drawer Bottom Rail 1 PC	Back Upper Rail 1 PC	Back Middle Rail 2 PCS	Back Panel 3 PCS
K 	L 	M 	N 	O 
Drawer Front Panel 2 PCS	Drawer Left Panel 2 PCS	Drawer Right Panel 2 PCS	Drawer Back Panel 2 PCS	Drawer Bottom Panel 2 PCS
P 	Q 	R 	S 	T 
Left Door Panel 1 PC	Right Door Panel 1 PC	Adjustable Shelf 1 PC	Caster 2 PCS	Locking Caster 2 PCS
U 	V 	W 		
Towel Bar Right Panel 2 PCS	Towel Bar Left Panel 2 PCS	Towel Bar 2 PCS		

HARDWARE LIST

#1  Ø8*30mm Wood Dowel 24 PCS (Extra 1)	#2  Bolt 8 PCS	#3  Knob 2 PCS	#4  Long Round Head Bolt 2 PCS (Extra 1)	#5  Handle 2 PCS
#6  Round Head Bolt 4 PCS (Extra 1)	#7  Cam Bolt 14 PCS	#8  Cam Lock 14 PCS (Extra 1)	#9  Shelf Holder 4 PCS	#10  Short Screw 16 PCS (Extra 1)
#11  Screw 2 PCS (Extra 1)	#12  Allen Wrench 1 PC			

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach knobs (part #3) to drawer front panels (part K) using long round head bolts (part #4) and phillips head screwdriver. Attach handles (part #5) to door panels (parts P & Q) using round head bolts (part #6) and phillips head screwdriver.




Step 2. Attach cam bolts (part #7) to panels and rail (parts A, B, C & H) using phillips head screwdriver.

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





Step 3. Attach drawer panels (parts L & M) to drawer front panel (part K) using short screws (part #10) and phillips head screwdriver. Slide drawer bottom panel (part O) into grooves of assembled unit (parts K, L & M). Attach drawer back panel (part N) to assembled unit (parts L, M & O) using short screws (part #10) and phillips head screwdriver. Repeat for remaining drawer.






#10  x 16

Step 4. Attach top cross rail (part F) to partition panel (part D) using screw (part #11) and phillips head screwdriver. Attach drawer bottom rail (part G) to partition panel (part D) using wood dowel (part #1), screw (part #11) and phillips head screwdriver. Attach back upper rail (part H) to partition panel (part D) using wood dowel (part #1) and cam lock (part #8).


NOTE: Cam locks must rotate a full 180°. See pictured insert.




#1  x 2
 #8  x 1
 #11  x 2

Step 5. Attach left panel (part B) to assembled unit (parts F, G & H) using wood dowels (part #1) and cam locks (part #8).


NOTE: Cam locks must rotate a full 180°. See pictured insert.





Step 6. Attach back middle rails (part I) and back panels (part J) to back upper rail (part H) and left panel (part B) using wood dowels (part #1).





Step 7. Attach bottom panel (part E) to assembled unit (parts B, I & J) using wood dowels (part #1), bolts (part #2) and allen wrench (part #12).





#1  x 6
 #2  x 2
 #12  x 1


Step 8. Attach right panel (part C) to assembled unit (parts E, F, G, H & J) using wood dowels (part #1), bolts (part #2), cam locks (part #8) and allen wrench (part #12).

NOTE: Cam locks must rotate a full 180°. See pictured insert.




#1  x 4
 #2  x 2
 #8  x 4
 #12  x 1

Step 9. Insert casters (parts S & T) into panels (parts B & C).




Step 10. Carefully turn unit upright. Attach towel bar right panels (part U) to panels (parts B & C) using wood dowels (part #1), bolts (part #2) and allen wrench (part #12). Attach towel bars (part W) and towel bar left panels (part V) to assembled unit (parts B, C & U) using wood dowels (part #1), bolts (part #2) and allen wrench (part #12).




#1  x 4
#2  x 4
#12  x 1

Step 11. Attach top panel (part A) to assembled unit (parts B, C, D & H) using wood dowels (part #1) and cam locks (part #8). Place shelf holders (part #9) into desired position and then slide adjustable shelf (part R) into place.

NOTE: Cam locks must rotate a full 180°. See pictured insert.



Step 12. Slide assembled drawers into place.



Step 13. Install left door panel (part P) to inner grooves of drawer bottom rail (part G) and bottom panel (part E). Install right door panel (part Q) to outer grooves of drawer bottom rail (part G) and bottom panel (part E).

