



























Entryway Bench CF6009



PART LIST


A		B		C		D		E	
Top Panel 1 PC		Bottom Panel 1 PC		Left Side Panel 1 PC		Right Side Panel 1 PC		Left Door 1 PC	
F		G		H		I		J	
Right Door 1 PC		Middle Vertical Panel 1 PC		Back Panel 1 PC		Leg 4 PCS		Support Leg 1 PC	
K									
Cushion 1 PC									

HARDWARE LIST


<div>#1</div> <div></div> <div>Ø 1/4"*1-3/4"</div> <div>Long Hex Socket Head Bolt</div> <div>9 PCS(Extra 1)</div>	<div>#2</div> <div></div> <div>Ø 1/4"*1-1/4"</div> <div>Short Hex Socket Head Bolt</div> <div>5 PCS(Extra 1)</div>	<div>#3</div> <div></div> <div>Ø 1/4"*1/2"</div> <div>Handle Bolt</div> <div>5 PCS(Extra 1)</div>	<div>#4</div> <div></div> <div>Ø 3mm*1/2"</div> <div>Screw</div> <div>21 PCS(Extra 1)</div>	<div>#5</div> <div></div> <div>Ø 3mm*5/8"</div> <div>Flat Head Screw</div> <div>9 PCS(Extra 1)</div>
<div>#6</div> <div></div> <div>Ø 8mm*1-1/8"</div> <div>Wood Dowel</div> <div>9 PCS(Extra 1)</div>	<div>#7</div> <div></div> <div>Ø 1/4"*11mm</div> <div>Spring Washer</div> <div>13 PCS(Extra 1)</div>	<div>#8</div> <div></div> <div>Ø 1/4"*13mm</div> <div>Flat Washer</div> <div>13 PCS(Extra 1)</div>	<div>#9</div> <div></div> <div>Handle</div> <div>2 PCS</div>	<div>#10</div> <div></div> <div>Magnet</div> <div>2 PCS</div>
<div>#11</div> <div></div> <div>Hinge</div> <div>2 PCS</div>	<div>#12</div> <div></div> <div>Allen Wrench</div> <div>1 PC</div>			


ADDITIONAL TOOLS(Not Provided)

Note:It is not recommended to use power tools during assembly.





Step 1. Attach magnets (part #10) to top panel (part A) using screws (part #4) and Phillips head screwdriver.



#10  x 2

#4  x 4


Step 2. Attach handles (part #9) to left and right door (parts E & F) using handle bolts (part #3) and Phillips head screwdriver.




#9  x 2

#3  x 4


- Step 3.** Attach left side panel (part C) and middle vertical panel (part G) to top panel (part A) using wood dowels (part #6), flat washers (part #8), spring washers (part #7), hex socket head bolts (part #2), and allen wrench (part #12). NOTE: DO NOT FULLY TIGHTEN BOLTS AT THIS TIME. Insert left door (part E) into left side panel (part C) and middle vertical panel (part G) as shown.
- NOTE: Please fully tighten bolts after door is installed.




- Step 4.** Close left door (part E) as shown, and attach right side panel (part D) to top panel (part A) using wood dowel (part #6), flat washers (part #8), spring washers (part #7), hex socket head bolts (part #2), and allen wrench (part #12). NOTE: DO NOT FULLY TIGHTEN BOLTS AT THIS TIME. Insert right door (part F) into right side panel (part D) and middle vertical panel (part G) as shown. NOTE: Please fully tighten bolts at this time.




Step 5. Close right door (part F) like left door (part E) in previous step. Carefully flip the unit upside down onto a soft surface such as carpet as shown. Attach bottom panel (part B) to left side panel (part C), middle verticle panel (part G) and right side panel (part D) using wood dowels (part #6), flat washers (part #8), spring washers (part #7), long hex socket head bolts (part #1), and allen wrench (part #12).




Step 6. Screw support leg (part J) into bottom panel (part B). Attach legs (part I) to bottom panel (part B) using flat washers (part #8), spring washers (part #7), long hex socket head bolts (part #1), and allen wrench (part #12). Additional details for proper installation of the support leg (part J) are available in Step 9.






Step 7. Carefully turn the bench upright. Attach back panel (part H) to assembled unit using screws (part #4) and Phillips head screwdriver.



#4  x 16

Step 8. Attach hinges (part #9) to left and right doors (parts E & F) and left and right side panels (parts C & D) using flat head screws (part #5) and Phillips head screwdriver.



#5  x 8
#11  x 2

Step 9. Put cushion (part K) into place. **IMPORTANT:** Adjust the support leg (part J) by unscrewing it until it fits tightly against the floor to ensure proper installation.

