





























Hall Tree
CF6036



PART LIST


A 	B 	C 	D 	E 
Left Frame 1 PC	Right Frame 1 PC	Top Panel 1 PC	Bottom Panel 1 PC	Front Panel 1 PC
F 	G 	H 	I 	J 
Back Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Partition Panel 1 PC	Fixed Shelf 1 PC
K 	L 			
Back Rail 2 PCS	Cross Rail 4 PCS			

HARDWARE LIST

#1  Ø8*30mm Wood Dowel 12 PCS (Extra 1)	#2  Cam Bolt 18 PCS	#3  Cam Lock 18 PCS (Extra 1)	#4  Bolt 4 PCS (Extra 1)	#5  Short Bolt 40 PCS (Extra 1)
#6  Flat Washer 8 PCS (Extra 1)	#7  Allen Wrench 1 PC	#8  Hook 10 PCS	#9  Flat Screw 20 PCS (Extra 1)	#10  Left Spring Hinge 1 PC
#11  Right Spring Hinge 1 PC	#12  Screw 8 PCS (Extra 1)	#13  Safety Strap Kit 1 SET		

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach cam bolts (part #2) to panels (parts C, D, E, F, G & H) using phillips head screwdriver. Attach hooks (part #8) to back rails (part K) using flat screws (part #9) and phillips head screwdriver.

NOTE: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




Step 2. Attach back rails (part K) and cross rails (part L) to frames (parts A & B) using short bolts (part #5) and allen wrench (part #7).




Step 3. Attach panels (parts G, H & I) to back panel (part F) using wood dowels (part #1) and cam locks (part #3). Attach front panel (part E) to assembled unit (parts G, H & I) using wood dowels (part #1) and cam locks (part #3).

NOTE: Cam locks must rotate a full 180°. See pictured insert.





Step 4. Attach assembled unit (parts E, F, G, H & I) to bottom panel (part D) using wood dowels (part #1) and cam locks (part #3).



NOTE: Cam locks must rotate a full 180°. See pictured insert.



Step 5. Attach top panel (part C) to assembled unit (parts F, G, H & I) using wood dowels (part #1) and cam locks (part #3).



NOTE: Cam locks must rotate a full 180°. See pictured insert.






#1  x 2
#3  x 5


Step 6. Attach spring hinges (parts #10 & #11) to panels (parts C, G & H) using screws (part #12) and phillips head screwdriver.

NOTE: Cam locks must rotate a full 180°. See pictured insert.



#10  x 1
#11  x 1
#12  x 8


Step 7. Attach assembled unit (parts E, F, G, H, I & D) to cross rails (part L) and frames (parts A & B) using bolts (part #4), short bolts (part #5), flat washers (part #6) and allen wrench (part #7).









Step 8. Attach fixed shelf (part J) to cross rails (part L) using short bolts (part #5), flat washers (part #6) and allen wrench (part #7).

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #13) must be installed to prevent tipping, damage and/or injury.



#13	A	B	C	D	E
			 D8*3/4"	 D8*1-1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION


Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1.Insert short screw (C) through washer (B) and safety wall strap (E) and attach to back rail (part K) using phillips head screwdriver.

2.Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in back rail (part K) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.

3.Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!